


# User Manual



Foaming Soap Dispenser  
(Touch Switch)

## Features



### Note on Mixing Liquid

Foaming function directly foamed soap liquid, non-foam type needs to be watered (5-8 times of water, add or subtract according to concentration)

### The Ratio of Foam to Water

Soap solution: Water = 1 : 5 ~ 1 : 8 (Normal Range)

Soap solution: Water < 1 : 5 ~ 1 : 8 (Easy to Plug)

Soap solution: Water > 1 : 5 ~ 1 : 8 (Bobble thinning)

## Attentions

- 1, Please place the unit on a flat level surface without water covering
- 2, Please use the liquid soap which contains low concentration of alcohol
- 3, Please turn off the unit first when you need to move it to prevent dispensing accidentally
- 4, Do Not flush the unit with the strong running water nor immerse the bottom of unit in the water, which may damage battery compartment
- 5, Do Not exposure the unit under direct the sun or strong light, which may interfere IR sensor system
- 6, If you won't use the dispenser for an extended period of time, please empty the container, clean it with dry soft towel and remove the batteries, store it in a dry place
- 7, Keep manual in a safe place for future reference

## Usage Method

Align the syringe ant the machine wash inlet and inject warm water (warm water has better effect on dissolving pipe sticky matter). Until there is water coming out of the foam outlet, repeat 2-3 times, and the effect is better.  
Note: Needle barrel is not included in package

